


Aristel

Powerphone *Quick Reference Guide*

Installation

After removing all of the Powerphone equipment from the packaging, identify the items supplied by referring to the diagram below.



Place the Connection Box close to the telephone line outlet, and a mains power outlet. Please note that the extension microphone and recording devices are optional and are not included in the standard package. Refer to the user guide for details on their use.

To get the best performance possible, position the Powerphone in the center of the surface where the unit is being used and at least 20cm from the edge. Try not to use it close to walls because it may cause an echo to the other party to the call.

If you are in a small room, then try the unit with only one or two microphones active. You can select the number of microphones active using the switch on the bottom of the Powerphone. In larger rooms you may need all three microphones active.

To optimise the speakerphones performance, ask the other party to the call if they can hear you clearly and adjust the volume control on the speakerphone to suit the call. This may assist in making the conversations clearer at both ends.

REMEMBER - TO TALK IN A NORMAL VOICE AND SPEAK TOWARDS THE POWERPHONE.